

Checking And Maintaining Car Tyre Pressure And Tread Unit Title:

Unit Level: Entry 3

Unit Credit Value: 1 10 GLH:

LASER Unit Code: WJC643 Ofqual Unit Code: M/506/0861

This unit has 2 learning outcomes.

LEARNING OUTCOMES		ASSESSMENT CRITERIA	
The learner will:		The learner can:	
1.	Be able to use relevant tools and equipment safely.	1.1	Select and safely use tyre pressure gauge, air line and inflator, tread gauge and tyre pressure charts for tasks.
2.	Be able to maintain tyres on a car.	2.1	Check all tyres for uneven wear and damage and record findings on a checklist.
		2.2	Identify legal tyre tread depth.
		2.3	Check tread depths of all tyres using a thead gauge and record on a checklist.
		2.4	Identify front and rear tyre pressure of a specified car from tyre pressure chart.
		2.5	Check all tyre pressure and increase or decrease to correct value using an air line pressure gauge and inflator.
		2.6	Remove dust caps, store and replace correctly when checking tyre pressure.

Assessment Guidance:				
NA				

Additional Information:	
NA	